



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Part # 19010600
Mustang II Front Black Series Shock Kit
For Use w/ CoolRide & Lower StrongArm

Components:

2	20000009	Black Series shocks – Eye/Eye
2	90001966	Shock sleeve
2	90000011	Weld-on upper shock bracket
2	90001618	Lower shock stud - .5" O.D.

Hardware:

4	99501003	1/2" x 2 1/2" USS bolt	Shock to upper bracket
4	99502001	1/2" USS Nylok nut	Shock to upper bracket



COOLRiDE[®]

by Air Ride Technologies

Installation Instructions



1. The upper shock mount must be welded to the frame. It may need to be cut down to match the stroke of the air spring and suspension. Make sure that when the suspension is fully compressed that the shock is about $\frac{1}{4}$ " from being fully compressed.

2. Tack weld the mount during initial fitment. The lower mount will be installed to the back side of the lower control arm.

3. Check to make sure the shock does not bottom out when the suspension is fully compressed. If the shock bottoms out it could damage the shock or shock mounts. Also check turning radius with the wheel. Once the final location is determined fully weld the upper mount to the frame.

