



Part # 33601200 - Gen 6 Camaro 1LE MagneTuner



Gen 6 Camaro 1LE MagneTuner Installation Instructions

Table of contents

Page 2.... Included components and Getting Started

Page 3.... OEM Module Removal & MagneTuner Installation





Major ComponentsIn the box

Part #	Description	QTY
33601201	MagneTuner Suspension Controller	1
31900001	USB Cable	1

Getting Started.....

1. Make sure the car is turned off.



2. Lift the trunk liner and locate the OEM controller.



3. Push the GRAY UNLOCK BUTTON, the connector will pop open. As you open this connector, it will pull the plug out of the ECU. Use light force and wiggle on the ECU and connector as you open the connector.

②



OEM Module Removal & MagneTuner Install



4. Remove the OEM Controller from the bracket and replace with the MagneTuner. **See Notes below before plugging in the connector.**

Check the bottom of the plug to make sure everything is still in place. There is a **WHITE** cover on the bottom, make sure it hasn't popped out of place. If it has, push it back in place.

BEFORE CONNECTING THE MAGNETUNER CONTROLLER, you must lubricate both the controller connector and the vehicle's wiring connector with NAPA Silicone Spray (8300), WD40, or comparable lubricant.

CAUTION: Check pin orientation before plugging in (note: we have heard it can be plugged in backwards)

5. As you plug the MagneTuner in to the OEM Harness, put light pressure on it as you close the lever on the OEM plug. **DO NOT** rely on the lever to pull it in unassisted.