

### Installation Instructions



## Part # 11059570 - 1958-1960 GM B-Body Steering Kit



#### **Recommended Tools**



# **Major Components** .....In the box

Part Number	Description
90000091	Tie Rod Adjuster
99800002	5/8"-18 Right Hand Jam Nut
99800003	5/8"-18 Left Hand Jam Nut
90003053	Inner Tie Rod - 10.750" Long(from grease zerk) - 5/8"-18 Right Hand Thread
90003046	Outer Tie Rod - 3.500" Long(from grease zerk) - 5/8"-18 Left Hand Thread
	90000091 99800002 99800003 90003053

#### **NOTES:**

This Tie Rod Adjuster is designed to take place of the OEM steel sleeve.

One end of the adjuster has a **groove** cut in it, this is the **LEFT HAND** threaded side.

When installing the Tie Rod Adjuster, use antisieze compound on the threads.

FOR YOUR SAFETY, THE TIE RODS NEED A MINIMUM 15/16" OF THREAD ENGAGEMENT INTO THE TIE ROD ADJUSTER. USE THE SIGHT HOLE IN THE SIDE OF THE TIE ROD ADJUSTER TO ENSURE PROPER THREAD ENGAGEMENT.