

### Installation Instructions



## Part # 11349570 - 1967-1970 C10 Steering Kit



#### **Recommended Tools**



# **Major Components** .....In the box

QTY	Part Number	Description
2	90000090	Tie Rod Adjuster
2	99800002	5/8"-18 Right Hand Jam Nut
2	99800003	5/8"-18 Left Hand Jam Nut
1	90003044	Idler Arm
2	90003048	Outer Tie Rod End - 7.250" Long(from grease zerk) - 5/8"-18 Left Hand Thread
2	90003049	Inner Te Rod End - 7.250" Long(from grease zerk) - 5/8"-18 Right Hand Thread
	·	

#### NOTES

This Tie Rod Adjuster is designed to take place of the OEM steel sleeve.

One end of the adjuster has a **groove** cut in it, this is the **LEFT HAND** threaded side.

When installing the Tie Rod Adjuster, use antisieze compound on the threads.

FOR YOUR SAFETY, THE TIE RODS NEED A MINIMUM 15/16" OF THREAD ENGAGEMENT INTO THE TIE ROD ADJUSTER. USE THE SIGHT HOLE IN THE SIDE OF THE TIE ROD ADJUSTER TO ENSURE PROPER THREAD ENGAGEMENT.