

Installation Instructions



Part # 11369570 - 1973-1982 C10 Steering Kit



Recommended Tools



Major ComponentsIn the box

QTY	Part Number	Description
2	90000138	Tie Rod Adjuster
2	99800000	11/16"-18 Right Hand Jam Nut
2	99800001	11/16"-18 Left Hand Jam Nut
1	90003044	Idler Arm
2	90003051	Outer Tie Rod End- 6.75" Long(from grease zerk) - 11/16"-18 Right Hand Thread
2	90003050	Inner Te Rod End- 8.625" Long(from grease zerk) - 11/16"-18 Left Hand Thread
1	90003069	Pitman Arm

This Tie Rod Adjuster is designed to take place of the OEM steel sleeve.

One end of the adjuster has a **groove** cut in it, this is the **LEFT HAND** threaded side.

When installing the Tie Rod Adjuster, use antisieze compound on the threads.

FOR YOUR SAFETY, THE TIE RODS NEED A MINIMUM 1 1/32" OF THREAD ENGAGEMENT INTO THE TIE ROD ADJUSTER. USE THE SIGHT HOLE IN THE SIDE OF THE TIE ROD ADJUSTER TO ENSURE PROPER THREAD ENGAGEMENT.

