

Installation Instructions



Part # 11369571 - 1983-1987 C10 Steering Kit



Recommended Tools



Major ComponentsIn the box

	_			
	QTY	Part Number	Description	
	2	90000138	Tie Rod Adjuster	
	2	99800000	11/16"-18 Right Hand Jam Nut	
	2	99800001	11/16"-18 Left Hand Jam Nut	
	1	90003068	Idler Arm	
	2	90003051	Outer Tie Rod End - 6.75" Long(from grease zerk) - 11/16"-18 Right Hand Thread	
	2	90003050	Inner Te Rod End - 8.625" Long(from grease zerk) - 11/16"-18 Left Hand Thread	
	1	90003069	Pitman Arm	
N.				

OTEC

This Tie Rod Adjuster is designed to take place of the OEM steel sleeve.

One end of the adjuster has a **groove** cut in it, this is the **LEFT HAND** threaded side.

When installing the Tie Rod Adjuster, use antisieze compound on the threads.

FOR YOUR SAFETY, THE TIE RODS NEED A MINIMUM 1 1/32" OF THREAD ENGAGEMENT INTO THE TIE ROD ADJUSTER. USE THE SIGHT HOLE IN THE SIDE OF THE TIE ROD ADJUSTER TO ENSURE PROPER THREAD ENGAGEMENT.