

## Installation Instructions



Part # 12109535 - 1970 Mustang Steering Kit (with OE Power Steering)



## **Recommended Tools**



## **Major Components** .....In the box

QTY	Part Number	Description
2	90000138	Tie Rod Adjuster
2	99800000	11/16"-18 Right Hand Jam Nut
2	99800001	11/16"-18 Left Hand Jam Nut
2	90003062	Inner Tie Rod - 10.500" Long(from grease zerk) - 11/16"-18 Left Hand Thread
2	90003063	Outer Tie Rod- 4.500" Long(from grease zerk) - 11/16"-18 Right Hand Thread
1 '	90003056	Idler Arm

## **NOTES:**

This Tie Rod Adjuster is designed to take place of the OEM steel sleeve.

One end of the adjuster has a **groove** cut in it, this is the **LEFT HAND** threaded side.

When installing the Tie Rod Adjuster, use antisieze compound on the threads.

FOR YOUR SAFETY, USE THE SIGHT HOLES IN THE SIDE OF THE TIE ROD ADJUSTER TO ENSURE PROPER THREAD ENGAGEMENT.

