



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632

www.ridetech.com

Part # 19010501
Mustang II Front HQ Series Shock Kit
For Use w/ CoolRide & Stock Lower Arm

Shock:

- | | | |
|---|------------|--------------------------------|
| 2 | 986-10-036 | HQ Smooth Body Shock Cartridge |
| 4 | 70011138 | 3/4" ID Shock Bushing |
| 4 | 90002102 | 1/2" ID Inner Sleeve |

Components:

- | | | |
|---|----------|-----------------------------|
| 2 | 90000011 | Weld-on upper shock bracket |
| 2 | 90000034 | Lower shock bracket |

Hardware:

- | | | | |
|---|----------|------------------------|------------------------|
| 4 | 99501003 | 1/2" x 2 1/2" USS bolt | Shock to upper bracket |
| 4 | 99502001 | 1/2" USS Nylok nut | Shock to upper bracket |
| 2 | 99371004 | 3/8" x 1 1/4" USS bolt | Lower bracket to arm |
| 2 | 99372002 | 3/8" USS Nylok nut | Lower bracket to arm |
| 4 | 99373003 | 3/8" SAE flat washer | Lower bracket to arm |

Shock Dimensions:

- | | |
|-------------|---------|
| Compressed: | 10 1/8" |
| Extended: | 14 7/8" |

COOL RiDE®

Installation Instructions



1. The upper shock mount must be welded to the frame. It may need to be cut down to match the stroke of the air spring and suspension. Make sure that when the suspension is fully compressed that the shock is about $\frac{1}{4}$ " from being fully compressed.

2. Tack weld the mount during initial fitment. The lower mount will be installed to the back side of the lower control arm.

3. Check to make sure the shock does not bottom out when the suspension is fully compressed. If the shock bottoms out it could damage the shock or shock mounts. Also check turning radius with the wheel. Once the final location is determined fully weld the upper mount to the frame.



Shock adjustment 101- Single Adjustable

Rebound Adjustment:

How to adjust your new shocks.


The rebound adjustment knob is located on the top of the shock absorber protruding from the eyelet or stud top. You must first begin at the ZERO setting, then set the shock to a street setting of 12.



-Begin with the shocks adjusted to the ZERO rebound position (full stiff). Do this by rotating the rebound adjuster knob clockwise until it stops.

-Now turn the rebound adjuster knob counter clock wise 12 clicks. This sets the shock at 12. (settings 21-24 are typically too soft for street use).


Take the vehicle for a test drive.



-if you are satisfied with the ride quality, do not do anything, you are set!

-if the ride quality is too soft increase the damping effect by rotating the rebound knob clock wise 3 clicks.

Take the vehicle for another test drive.



-if the vehicle is too soft increase the damping effect by rotating the rebound knob clock wise 3 additional clicks.

-If the vehicle is too stiff rotate the rebound adjustment knob counter clock wise 2 clicks and you are set!

Take the vehicle for another test drive and repeat the above steps until the ride quality is satisfactory.

Note:

One end of the vehicle will likely reach the desired setting before the other end. If this happens stop adjusting the satisfied end and keep adjusting the unsatisfied end until the overall ride quality is satisfactory.